

LEDORIENTALIGHT


Installation Guide for T8 LED Tube

Case 1 : Fixture with magnetic ballast



* If your fluorescent fittings come with magnetic/ electronic ballast & starter, make sure to remove both ballast & starter.

Case 2 : Fixture with electronic ballast



* If your fluorescent light come with electronic ballast, the internal wiring of such fixture must be reconnected to have the electronic ballast / starter removed as shown

